



THE PLANT THIRST-QUENCHER TEKNO POKER 4 PIECES

Code: 5400511

waters the plants up to 45 days

PACKS

Blister with 4 tekno.

Charateristics

Waters the plants at home, in the balcony and in the kitchen garden while you're away easily, safely and without using electric power. The water is released drop by drop, round the clock, and the plants are watered correctly up to 45 days depending on the selected setting.

How to use

choose the most suitable setting depending on the plant. Insert the point into the bottle. Pierce the bottom of the bottle using a nail or a pin. Drive the point upright into the soil keeping a suitable distance from the stalk of the plant and paying attention that the water outlet hole in the dripper is far enough from the soil.